


# TX40 & T20 Second Stage Diagram



All items in brackets are to be replaced when servicing

1.	AP2037	Deflector	16.	AP2040	Exhaust tee
2.	AP2031	Nut	17.	AP2039	Venturi lever
3.	AP5002	Heat exchanger	18.	AP2033	Seat
(4)	AP1267	'O' ring	(19)	AP1154	'O' ring
5.	AP5004/1	Decal	20.	AP2048	Valve spindle
6.	AP2053	Purge button	21.	AP2035	Lever
7.	AP2020	Spring	22.	AP2047	Valve spindle cap
8.	AP2026	Case cover	(23)	AP1267	'O' ring
9.	AP2025	Diaphragm cover	24.	AP2046	Spring plug
10.	AP2023	Diaphragm	25.	AP2038	Counter balance cylinder
11.	AP5001	Case	26.	AP2021	Spring
12.	AP1429	Exhaust valve	(27)	AP2041	'O' ring
(13)	AP1438	'O' ring	28.	AP2036	Shuttle valve
14.	AP1434	Mouthpiece	(29)	AP2034	Rubber seating
15.	AP1677	Mouthpiece clip			