



Item	Part #	Description
1B	G1003-45	Origin purge Button
4B	G1014-36	Origin, spring
5B	G1077-05	Origin faceplate, black
	G1077-14	Origin faceplate, yellow
6B	G8210-32	Origin, thrust washer
2A	G1079-27	Axis color ring
3A	G1079-22	Axis retaining ring
5A	G1079-23	Axis purge cover
6A	G1079-24	Axis support cone
7	G1005-71	Diaphragm
8	G1085-10	LP seat
9	G1049-03	Poppet
10	G1085-15	Spring (red)
	G1085-14	Spring, octopus
11	G1005-23	Baffle
12	R015B	O-ring
13	G1005-14	Insert
14	G8450-22	Washer
15	G1085-13	Lever
16	F1025-17	Spacer
17	G1025-10	Locknut

Item	Part #	Description
18	G1079-14	Exhaust Tee
19	G1003-24	Plug
20	R905B	O-ring
21	G1003-89	Alignment key
22	G1005-12	Exhaust valve
23	G1049-13	Tie wrap
24	G1005-03	Case
25	G1058-31	Mouthpiece, Origin
	G1058-41	Mouthpiece, Axis
26	R014B	O-ring
27	G1004-44	Inlet fitting
28	R010B	O-ring
29	LPH-31	hose, 31"
	LPH-36	hose, 36"
	LPH-39	hose, 39"
	LPH-48	hose, 48"
	LPH-60	hose, 60"
30	R011B	O-ring
31	G1079-17	Hose protector
32		Decal, Origin