

TB30

JUL 11, 2017

First stage with CWD kit: intermediate pressure setting range

The following applies immediately. The intermediate pressure setting range for Mares Diaphragm 1ST stage with CWD kit is the same range as all Mares Diaphragm 1ST stages except for Abyss 22 Navy ÿ 1ST stage as below .

All Mares diaphragm 1ST stages with/without CWD kit

IP DOG	IP BAR
142 - 148	9.8 - 10.2

Abyss 22 Navy ÿ 1st stage

IP DOG	IP BAR
127 - 136	8.7 - 9.47



warn

All service and repair procedures for Mares products must be performed by authorized Mares service technicians at authorized Mares dealers and service centers. Service technicians should have the Mares Service Manual and Spare Parts Catalog readily available and strictly follow the recommended procedures and guidelines contained in these materials.